



Airdistributor

Datasheet

Date: 10/12

LV000120 Air distributor
2 Air outlet with measuring valve
Dimensions: 95mm x 108mm x 45mm
Size: ½"



Measuring valves for connection of a pressure gauge to display the pressure in the waveguide, when the shut off valve is closed

LV000121 Air distributor
2 Air outlet without measuring valve
Dimensions: 95mm x 108mm x 37mm
Size: ½"



LV000125 Air distributor
2 Air outlet without measuring valve
Dimensions: 95mm x 86mm x 37mm



Size:
Inlet ½"
Outlet ¼"

LV000140 Air distributor
4 Air outlet with measuring valve
Dimensions: 300mm x 114mm x 48mm
Size: ½"




Measuring valves for connection of a pressure gauge to display the pressure in the waveguide, when the shut off valve is closed

LV000141 Air distributor
 4 Air outlet without measuring valve
 Dimensions: 300mm x 114mm x 39mm
 Size: 1/2"



LV000145 Air distributor
 4 Air outlet without measuring valve
 Dimensions: 300mm x 92mm x 39mm
 Size:
 Inlet 1/2"
 Outlet 1/4"



LV000100 Air distributor
 6 Air outlet with measuring valve
 Dimensions: 300mm x 114mm x 48mm
 Size: 1/2"
 Measuring valves for connection of a pressure gauge to display the pressure in the waveguide, when the shut off valve is closed



LV000101 Air distributor
 6 Air outlet without measuring valve
 Dimensions: 300mm x 114mm x 39mm
 Size: 1/2"



LV000105 Air distributor
 6 Air outlet without measuring valve
 Dimensions: 300mm x 92mm x 39mm
 Size:
 Inlet 1/2"
 Outlet 1/4"



LV000150 Air release valve
for ventilation waveguide

Dimensions: 35mm x 114mm x 79mm

Size: ½"



LV000155 Air hose reducer

Dimensions: 22mm x 22mm x 60mm

Size: ½" – ¼"



LV000180 Air distributor

2 x 4 Air outlet with measuring valve

Dimensions: 300mm x 114mm x 48mm

Size: ½"

Measuring valves for connection of a pressure gauge to display the pressure in the waveguide, when the shut off valve is closed




LV000200 Air distributor

6 Air outlet with measuring valve in stainless steel housing


Dimensions: 300mm x 200mm x 80mm

Size: ½"

Measuring valves for connection of a pressure gauge to display the pressure in the waveguide, when the shut off valve is closed




LV000205 Air distributor
6 Air outlet in stainless steel housing
Dimensions: 300mm x 200mm x 80mm
Size: 1/4"



LV000603 Air distributor
6 Air outlet with pressure gauge
Dimensions:
Size: 1/2"

Pressure gauge to measure the pressure
in the waveguide



Friedl & Müller
Gerätebau GmbH Karl-Benz-Str. 14
85221 Dachau
Telefon 0 81 31 / 31 33 2-0 Telefax 0 81 31 / 1 55 45
<http://www.friedl-mueller.de>
e-mail: info@friedl-mueller.de
Änderungen vorbehalten - Specifications subject to change